

Jaku User Guide



3-way adjustable arm rests

(forward/back, side-to-side, up and down)
Press button to adjust arms.




height adjustable lumbar

Place hands on left and right sides to glide up or down.



seat depth

Lift lever and hold, slide seat forward or back, and release lever to lock.




back tension

Controls resistance to body weight.
Turn knob forward for more resistance and backward for less.




Smart Sync Mechanism



seat height adjustment

To raise the chair, lift your body weight and pull lever up. To lower the chair, stay seated and pull lever up.



back stop

4 comfort settings. Set recline angle by rotating the paddle to any of the four positions. When the paddle is horizontal, the back will allow you to fully recline.

Jaku User Guide



3-way adjustable arm rests

Adjusts forward/back, side-to-side, up and down.
Press button to adjust arms.



height adjustable lumbar

Place hands on left and right sides to glide up or down.



seat depth

Lift lever and hold, slide seat forward or back, and release lever to lock.



seat height adjustment

To raise the chair, lift your body weight and pull lever up. To lower the chair, stay seated and pull lever up.



Step Sync Mechanism



back tension

Controls resistance to body weight.
Turn knob clockwise for more resistance and counterclockwise for less



back lock

Position locking mechanism
Set lock by pushing down the paddle.